



## Connection between RadonixPC-Pro and JMC JASD



**RadonixPC-Pro (DB15F)**

**JASD**

RadonixPC-Pro Pins	Description	JASD
1	VCC +24 V	11
2	Direction -	37
3	Direction +	36
4	Pulse -	41
5	Pulse +	43
6	Servo On	9
7	Ready	7
8	Encoder Zero	48
9	Alarm Reset	10
10	Ground	
11	Ground	
12	Ground	6
13	Ground	44
14	Ground	
15	Ground	